



NOTE: To trim load cells individually install Summer Box PT100SB



PT100LC LOADCELL TRANSMITTER
DIMENSIONS AND WIRING SCHEMATIC

UNITS: mm	ISSUED:	BY:	DRAWN: 23-11-2004	©
SCALE: NTS	CHANGE:		REVISION: 00 DATE: 23-11-04	
CHKD:	APPROVED:		DWG No.: ACC\APLN\PT100LC	